## **Controls & Sensors**



## SEN-HY

Electronic humidistat to automatically activate/deactivate the ventilation unit when the R.H. goes over/ beneath the set threshold. Front graduated knob to adjust the humidity threshold between 50% and 95% R.H. Integral over-run timer adjustable from 1 to 25 minutes. Front yellow led to indicate that the load is active: - led on means that the ambient humidity is higher than the pre-set level - Blinking means that the with relay on but humidity level under threshold (timing in

progress) IP40 protection degree 230V~ 50-60 Hz Max. load 2A Ambient temperature from 0°C to +35°C Relative Humidity 95% at 35 °C Available for surface or recessed mounting.